

INSTALLATION INSTRUCTIONS

102051 NOx SOLENOID DRIVER MODULE

1. REMOVE TWO SCREWS SECURING ORIGINAL MAP SENSOR, THEN INSTALL NEW SENSOR AS SHOWN, USING TWO LONG SCREWS PROVIDED IN KIT.

KIT INCLUDES LOOP OF PLASTIC HOSE AND TEE, AND PERMITS INSTALLATION OF NEW 2-BAR MAP SENSOR.

ORIGINAL MAP SENSOR ON BRACKET NEAR FIREWALL IN REAR OF ENGINE BAY

3. INSERT ELBOW INTO HOSE FROM KIT, THEN INTO NEW MAP SENSOR.

4. INSERT BOOST HOSE ON ENGINE INTO TEE, THEN PLUG INTO EXISTING MAP SENSOR.

2. REMOVE ELBOW AND PULL BOOST HOSE OUT.

OXYGEN SENSOR ON REAR HEADER

