

# INSTALLATION INSTRUCTIONS

## 107111 Crank Sensor Assembly 1986-1989

### 107111 Crank Sensor 1986-1989

Interrupter gap clearance of 0.020" minimum must be set when installing into vehicle.

Interrupter passes thru THIS slot

NOT this slot

Loosen bolt and slide the sensor to position the interrupter blade in the center of the slot. Be sure the interrupter doesn't hit the sensor body. Tighten the bolt once it is set.

Do not overtighten the bolt as damage to the sensor may occur. Be sure it is snug, but not too tight.

