

# INSTALLATION INSTRUCTIONS

## 108027 ECM Splice Pair – Turbo Buick

**NOTE: Wire colors shown in <brackets> were used on factory installed engine harnesses in 1987. Caspers has modified some wire colors by adding stripes to the basic wire colors for ease of installation. Note that the wire colors used may not match "aftermarket" service manuals or on-line wire diagrams.**

