INSTALLATION INSTRUCTIONS 109050 A/F (AIR-FUEL) PIGTAIL CONNECTOR PLUGS INTO PRE-CAT OXYGEN SENSOR CONNECTOR SIGNAL WIRE GOES TO A/F MONITOR





