

LockSim™

Corvette Steering Column Lock Defeat Module

Part number 109072

This module is designed to defeat the steering column locking function associated with the anti-theft system. It is a simple Plug-And-Play device that installs between the lock mechanism connector and its mating connector. The module provides correct feedback signal to the BCM to prevent a malfunction code from being set, which would disable fuel to the engine if the code were set. The steering column remains unlocked at all times regardless of ignition key position.

To access the steering lock connector in your 1997-2002 Corvette:

1. Remove the Trunk Release-Fog Lamp switch cover by pulling it away from the dash. Unplug its connector and remove the screw located behind the connector.
2. Remove the kneepad by accessing two screws under it.
3. There may be an air temperature sensor cover which will need to be removed with a single screw.
4. Once the kneepad is removed, you can access the small rectangle connector leading to the steering column lock. Unplug this connector by gently prying up on the lock that retains the connector.
5. Install the new module between the two connectors. They can only fit one way.
6. Test the steering column lock by turning on the ignition. If all works properly, re-assemble all of the above items.
7. If an error code is set, remove fuses 23 and 25 for 15 seconds to reset the code.

