

FAST "A-K" CONNECTOR	NOTES	BUICK ECM WIRING	XFI ECU PINS
A1	MAP SIGNAL	B6	C20
A2			
A3			
B1	TPS SIGNAL	C13	C21
B2			
B3			
C1	COOLANT SENSOR	C10	C23
C2			
C3	CAM HI	A11	A4
D1	AIR TEMP SENSOR	C11	C22
D2			
D3			
E1	5 VDC	C14	C24
E2	SENSOR GND	D12	C11
E3			
F1	WBO2 "F" BLUE	-	C5
F2	WBO2 "E" GRAY	-	C4
F3	WBO2 "B" WHT	-	C1
G1	WBO2 "G" YEL	-	C6
G2	WBO2 "C" RED	-	C3
G3	WBO2 "A" BLK	-	C2
H1	ESC	B7	A9
H2			
H3			
J1			
J2	CRANK LO	B3	A13
J3	CRANK REF HI	B5	A8
K1			
K2	EST BYPASS	D5	A15
K3	EST CONTROL	B4	A14

