

FAST "L-Y" CONNECTOR	NOTES	BUICK ECM WIRING	XFI ECU PINS
L1	O2 SIGNAL	D7	-
L2			
L3	SWITCHED 12V	A6	B17
M1	MEM FEED 12V	C16	B18
M2	ANALOG GND	D1	B24
M3	DIGITAL GND	A12	B8
N1	RS232 RED	-	C27
N2	RS232 BLACK	-	C28
N3	RS232 WHITE	-	C29
P1	IAC "A" LO	C6	B13
P2	IAC "A" HI	C5	B12
P3			
R1	IAC "B" LO	C3	B15
R2	IAC "B" HI	C4	B14
R3	COOLANT FAN	D2	B10
S1	INJ 8 (NOT USED)		
S2	INJ 1	D14	D9
S3	FUEL PUMP RELAY	-	B5
T1	INJ 7 (NOT USED)		
T2	INJ 2	C15	D7
T3			
W1	INJ 5	B12	D13
W2	INJ 3	D15	D4
W3			
X1	INJ 6	C12	D11
X2	INJ 4	D16	D2
X3			
Y1	GND RETURN	-	A12
Y2	GND RETURN	-	B7
Y3	GND RETURN	-	D1

