



# Oil Pressure Switch



This switch is designed to send a "Low Oil Pressure" indicator when the oil pressure goes below 2PSI. Also, it will pair up with the Fuel Pump Relay contacts when oil pressure is above 2PSI. Pairing takes the load partially off the Fuel Pump Relay contacts.



**A**

- A - Pink/Blk (switched +12V)**
- B - Tan (LOW OIL dash lamp\_**
- C - Gray (to fuel pump)**